



BATTERY CHARGER - STARTERS



MODEL	FOR	USE	FEATURES	IN / OUTPUT	WEIGHT Kg.
RAPID 460	MAX. 260 AMP HOUR BATTERIES	CAR WORKSHOPS AGRICULTURE FLEET OWNERS STARTING DIESEL ENGINES UP TO 70 HP.	6 SETTINGS PLUS BOOST STEEL HOUSING, AMMETER AUTOMATIC OVERCHARGE & REV. POLARITY PROTECTION. VOLTAGE & CHARGE SELECTION	240 VOLT 12 / 24 VOLT 30 AMP	20
SPRINTCAR 340	MAX. 250 AMP HOUR BATTERIES	PROFESSIONAL WORKSHOPS, AGRICULTURE FLEET OWNERS STARTING DIESEL ENGINES UP TO 50 HP.	4 SETTINGS PLUS BOOST STEEL HOUSING, AMMETER AUTOMATIC OVERCHARGE & REV. POLARITY PROTECTION. VOLTAGE & CHARGE SELECTION	240 VOLT 12 / 24 VOLT 30 AMP	18
SPRINTCAR 540	MAX. 350 AMP HOUR BATTERIES	PROFESSIONAL WORKSHOPS, AGRICULTURE FLEET OWNERS STARTING DIESEL ENGINES UP TO 80 HP.	6 SETTINGS PLUS BOOST STEEL HOUSING, AMMETER AUTOMATIC OVERCHARGE & REV. POLARITY PROTECTION. VOLTAGE & CHARGE SELECTION	240 VOLT 12 / 24 VOLT 40 AMP	28
SPRINTCAR 640	MAX. 400 AMP HOUR BATTERIES	PROFESSIONAL WORKSHOPS, AGRICULTURE FLEET OWNERS STARTING DIESEL ENGINES UP TO 90 HP.	6 SETTINGS PLUS BOOST STEEL HOUSING, AMMETER AUTOMATIC OVERCHARGE & REV. POLARITY PROTECTION. VOLTAGE & CHARGE SELECTION	240 VOLT 12 / 24 VOLT 50 AMP	30

* Product Specifications Subject To Change Without Notice *

DISTRIBUTED BY :

AWE
AUSLINK
WELDING & ENGINEERING
 23 Research Drive Croydon Vic. 3136
 Ph: 03.9761.4915 Fax: 03.9761.4916

SUPPLIED BY :

World Wide Web site, www.ausmig.com.au

E-mail, sales@ausmig.com.au